

## #81582 - Low Visibility Wheelie Bars for the Traxxas X-Maxx

**What's Included:** 1 - tree (containing 1 - Wheelie Bar Bracket & 2 - Nylon Wheels), 4 - M3 x 12mm flathead screws, 2 - M4 x 25mm buttonhead screws, 4 - M4 washers, 2 - 4mm locknuts & 2 aluminum bushings.

**Required:** You must have an **RPM #81762** X-Maxx Rear Bumper Mount (not included) in order to install **RPM** Low Visibility Wheelie Bars. They will not work with stock or any other known aftermarket rear bumper mounts.

**Before You Begin:** If you've already installed an **RPM #81762** X-Maxx Rear Bumper Mount, it will be easier if you remove it to install your new Wheelie Bars but not necessary. Carefully trim the Wheelie Bar Bracket and Wheels off of the parts tree, removing any burrs from the wheels at that time.

**Installation:** Refer to the illustration below for a visual reference. Start by installing the **RPM** wheels on the wheelie bar bracket. Install the assembly in exactly this order:

M4 x 25mm buttonhead screw / 4mm washer / aluminum bushing / **RPM** wheel / 4mm washer / **RPM** wheelie bar bracket / 4mm locknut. **Caution:** *The smooth, flat side of the 4mm washers should rest against the wheel.* Do not over-tighten the screw since the wheel needs to rotate freely.

Once both wheels are installed, bolt the bracket to your #81762 bumper mount using the 4 included M3 x 12mm flathead screws.

Finally, install (or reinstall) your #81762 bumper mount on to your truck.

**Note:** **RPM** wheelie bars are primarily designed to help protect the rear bumper and are not designed for long-distance / extended wheelies or to prevent flips.

