

1:12 Scale Ready-To-Run Electric 4x4 Monster Van Manual & Catalog





#### :: Introduction

Thank you for purchasing this Team Associated product. This assembly manual contains instructions and tips for building and maintaining your new RTR. Please take a moment to read through this manual to help familiarize yourself with these steps. We are continually changing and improving our designs; therefore, actual parts may appear slightly different than in the illustrations. New parts will be noted on supplementary sheets.

#### :: Vehicle Features

- Open front and rear differentials
- Steel pivot balls
- Steel 4-link bars
- Servo on chassis steering
- Steel C-channel frame rails
- Servo saver
- Fluid-filled shocks with threaded shock bodies
- Adjustable shock holes on towers
- Aluminum wheel hexes
- Adjustable front and rear body posts
- Metal front CVA and rear solid axle shafts with 12mm hex adapters
- Black anodized aluminum battery/radio tray with hook and loop hold-down strap
- Plastic low-friction slider-type drive shafts
- 16-piece metal-shield ball bearing set
- 2.4GHz XP transmitter and receiver
- Reedy Power speed control with high-current T-plug connector
- Reedy brushed 380 motor
- 850mAh Li-Ion 7.4V 2-cell battery and charger

#### :: Additional

Your new RTR comes factory assembled including radio gear, motor, and ESC.

However, there are some items you will need to complete your kit (refer to website for suggestions):

• AA-size batteries for transmitter (x4)

#### :: Other Helpful Items

- Silicone Shock Fluid (Refer to website for complete listings)
- Green Slime shock lube (AE # 1105)
- Thread Locking Compound (AE # 1596)
- 7 Piece Hex Driver Set (AE # 1650)
- Calipers or a Precision Ruler

- Silicone Diff Fluid (Refer to website for complete listings)
- Cyanoacrylate glue (AE # 1597)
- Body Scissors (AE # 1737)
- FT Nut Drivers (AE #1519)
- Reamer / Hole Punch
- Hobby Knife
- Wire Cutters
- Soldering Iron
- Needle Nose Pliers

Associated Electrics, Inc. 21062 Bake Parkway. Lake Forest, CA 92630



Customer Service Tel: 949.544.7500 Fax: 949.544.7501

# :: Hardware - 1:1 Scale View

2x10mm (41072)
<b>2.5x6mm</b> (31520)
<b>2.5x8mm</b> (31521)
<b>2.5x10</b> mm (31522)
<b>2.5x12</b> mm (21582)
<b>2.5x14</b> mm (41073)
<b>2.5x18</b> mm (81259)
<b>2.5x20</b> mm (41074)
<b>2.5x25mm</b> (41075)
<b>3x4mm</b> (91158)
<b>3x8mm</b> (31532)
3x10mm (25211)
<b>3x20mm</b> (25188)

	<b>2.5x10mm</b> (31350)
	<b>2.5x12mm</b> (41076)
	<b>3x6mm</b> (31541)
	<b>3x8mm</b> (25201)
	<b>Screws (shcs)</b> 2x4mm (41070
_	<b>2x4mm</b> (41070)
	2x4mm (41070) 2x5mm (31511)
	2x4mm (41070) 2x5mm (31511) 2x8mm (7187) 2.5x6mm (41079)
	2x4mm (41070) 2x5mm (31511) 2x8mm (7187)
	2x4mm (41070) 2x5mm (31511) 2x8mm (7187) 2.5x6mm (41079)

Bearings	<b>5x10x4mm</b> (91560)
	<b>10x15x4mm</b> (91563)
Set Screws	<b>2.5x5mm</b> (41119)
	2.5x5mm (41119) 3x3mm (25225)

#### Notes:

### :: Table of Contents

1..... Cover

2.....Introduction

3.....1:1 Hardware "Fold Out"

4.....Table of Contents

5 - 7.....Quick Start Guide

8.....Shock Build

9.....Gear Differential Build

9 - 11.....Front / Rear Suspension Build

12 - 13......Drivetrain Build

13 - 16.....Electronics Build

16 - 17.....Tires and Body Build

18..... Back Cover

#### :: Notes



This symbol indicates a special note or instruction in the manual.



This symbol indicates a Racers Tip.



There is a 1:1 hardware foldout page in the front of the manual. To check the size of a part, line up your hardare with the correct drawing until you find the exact size. Each part in the foldout has a number assigned to it for ordering replacement parts.

Associated Electrics, Inc. 21062 Bake Parkway. Lake Forest, CA 92630



Customer Service Tel: 949.544.7500 Fax: 949.544.7501 9/23

### :: Quick Start Guide

# **Battery Charging Steps and Safety:**

Remove the battery from the vehicle before charging. Place battery on a fire resistant surface. Avoid any contact with water or other liquids. Be sure to select the correct charging mode for the type of battery you are charging (if aplicable).

**ALWAYS** use a compatible charger for charging your batteries.

Caution: Never leave the battery unattended while charging. Always disconnect the charger from the power source when finished charging.

Caution: Always disconnect the battery when you are finished driving the vehicle.




# :: Quick Start Guide - (cont.)

## **Battery Installation:**


- 1. Install the battery with the battery wires directed towards the front of the vehicle.
- 2. Secure the hook and loop strap.

You may move the foam pad to either the front or the rear of the battery compartment to adjust the weight balance of the vehicle.





### :: Quick Start Guide - (cont.)



### :: Quick Start Guide - (cont.)

## **Battery Notes and Tip:**

Connect the battery as shown.

Disconnect the battery when not in use!

**LiPo/LiLo:** LiPo/LiLo batteries (lithium polymer/Lithium lon) are high current rechargeable batteries. LiPo/LiLo batteries offer extended run time and peak performance over NiMH batteries. They require a peak detection charger designed specifically for LiPo/LiLo batteries.

These batteries require special care and handling. LiPo/LiLo batteries are recommended for advanced users only!

ALWAYS charge a LiPo/LiLo battery in LiPo/LiLo mode.



# :: Quick Start Guide - (cont.)

#### **Radio System Tuning and Controls:**

RULE: Transmitter on First/Vehicle on Second, Vehicle off First/Transmitter off Last!

- 1) Slide the battery cover to remove cover.
- 2) Install alkaline or rechargeable AA size batteries into the battery holder.
- 3) Slide the battery cover back into place making sure it is completely closed and secure.
- 4) Turn the power ON. If the power indicator LED fails to light, check the batteries for insufficient contact or incorrect polarity.





# :: Quick Start Guide - (cont.)

## **Radio System Tuning and Controls:**

**DO NOT** hold the trigger when turning on the radio.


If using optional battery for transmitter, be sure to plug it in correctly. Plugging in a battery backwards can cause damage.

Refer to Radio owners manual for more in-depth instructions on radio operation and functions.


Adjust steering trim so front wheels point straight.










# :: Quick Start Guide - (cont.)





Install body and body clips. Ready to go!




































































# FIND IT ON ASSOCIATEDELECTRICS.COM

CARS & TRUCKS



Vehicle Spare Parts
GO TO:
AssociatedElectrics.com
Team Associated tab
Cars & Trucks
Scroll to your vehicle
Parts & Accessories link



Setups and Manuals
GO TO:
AssociatedElectrics.com
Team Associated tab
Manuals & Setups
Scroll to your vehicle

A-TEAM APPS

WEB APPS

Tuning Guides & Tips
GO TO:
AssociatedElectrics.com
Support
A-Team Apps



Associated Electrics, Inc.
21062 Bake Parkway Lake Forest, CA 92630 USA

call: (949) 544-7500 - fax: (949) 544-7501
Check out the following web sites for all of our kits, current products, new releases, setup help, tips, and racing info!

www.AssociatedElectrics.com

#### FOLLOW US ON SOCIAL MEDIA



TeamAssociated ReedyPower



@TeamAssociatedRC @ReedvPower



@Team\_Associated @ReedvPower